Samsung **DVD-V6700** DVD/VHS combo

Press the **GREEN** **ON** button to turn on the multimedia projector
The projector takes about a minute to warm up

To change the **'source'** press the **GREEN** button to select
Computer, **Video** or **DVD**

Turn the projector off by pressing the **RED** **OFF** button
The message **Please wait a moment** will display on the screen
It takes about 90 seconds for the projector to shut down

Please remember to turn all equipment off when you are finished

Volume control *

AV POWER turns on the loud speakers
and power for the DVD/VHS player

If you require a Remote control it is available for loan from Multimedia Resources in the library

Select DVD/VCR

***in some rooms this control knob is not present. In these rooms use volume controls indicated here**